세종문화회관 대극장 무대평면도

SEJONG CENTER FOR THE PERFORMING ART GRAND THEATER STAGE PLAN

No.	SPEED (m/min)	LENGTH (m)	TYPE	SET
1	0~60	23	B	
2	0~60	29	C	
3	0~60	29	A	
4	0~60	29	A	
5	0~60	29	B	
6	0~60	29	A	
7	0~60	29	B	
8	0~60	29	A	
9	0~60	29	A	
10	0~60	29	A	
11	0~60	29	A	
12	0~60	29	A	
13	0~60	29	A	
14	0~60	29	A	
15	0~60	29	A	
16	0~60	29	B	
17	0~60	29	B	
18	0~60	29	A	
19	0~60	29	A	
20	0~60	29	A	
21	0~60	29	A	
22	0~60	29	A	
23	0~60	29	A	
24	0~60	29	A	
25	0~60	29	A	
26	0~60	29	A	
27	0~60	29	A	
28	0~60	29	A	
29	0~60	29	A	
30	0~60	29	A	
31	0~60	29	A	
32	0~60	29	A	
33	0~60	29	A	
34	0~60	29	A	
35	0~60	29	A	
36	0~60	29	A	

A Type : WINCH & WEIGHT

B Type : WEIGHT

C Type : WINCH

무대 기계 개요

(Organization of Stage)

회전무대 (Revolving Stage)	0~60rpm (최대 1*360도)						
승강무대 (Plat Form)	UP	High	69 sec		DOWN	High	85 sec
		Low	210 sec			Low	210 sec
소형승강무대 (Small Plat Form)	UP	High	98 sec		DOWN	High	98 sec
		Low	195 sec			Low	195 sec
오케스트라 플랫트 (ORCHESTRA Plat Form)	UP	1m	High	25sec	DOWN	1m	25 sec
			Low	50sec			
		2.54m	High	42sec		2.54m	42 sec
			Low	83sec			
		4.2m	High	105 sec		4.2m	105 sec
			Low	210sec			
이 동 무 대 (Stage Truck)	IN	0~55m/min		OUT	0~55m/min		
본 막 (Main Curtain)	UP	0~40m/min		DOWN	0~40m/min		
하우스커튼 (House Curtain)	UP	0~40m/min		DOWN	0~40m/min		
양막 No.1, 2, 3, 4 (Side Curtain) RIGHT, LEFT 각 1조씩	UP	0~40m/min		DOWN	0~40m/min		
	OPEN	0~20m/min		CLOSE	0~20m/min		
양막 No.5 (Side Curtain)	UP	0~40m/min		DOWN	0~40m/min		
배경막(White Horizont)	UP	0~40m/min		DOWN	0~40m/min		
후경영사막(Rear Screen)	UP	0~40m/min		DOWN	0~40m/min		
흑배경막(Black Horizont)	UP	0~40m/min		DOWN	0~40m/min		
Proscenum Arch	WIDE	18~22m		High	12m		
장치의 높이 (High of Setting on the Stage Truck)	무 대 (Stage)			6m 90cm			
	지 하 실 (Under Stage)	Left		4m 70 cm			
		Right		4m 70cm			



범례(Legend)

	SET BATTEN
	MAIN CURTAIN
	HOUSE CURTAIN
	SIDE CURTAIN
	ACOUSTICAL SHELL
	WHITE HORIZONT
	REAR SCREEN
	BLACK HORIZONT
	SUB MIC POCKET
	MULTI POCKET
	STAGE MAIN PATCH
	PANORAMA
	AIR CONDITION